

SWISS ARMY VEHICLES

Service Information for Steyr Puch Pinzgauer

Instructions for Red Brake Light Conversion

- Remove Taillight Lenses
- Remove all Bulbs
- Remove old Bulb Socket
- Install new Bulb Sockets
The part of the socket with 2 contacts goes on the bottom

Rear LH Wire Hookup

Wire Color

- brown = socket ground terminal
- white/black = socket Turnsignal (upper terminal)
- black = socket Taillight (bottom left)
- pink = socket Brakelight (bottom right)

Rear RH Wire Hookup

Wire Color

- brown = socket ground terminal
- green/black = socket Turnsignal (upper terminal)
- grey = socket Taillight (bottom left)
- pink = socket Brakelight (bottom right)

- Reinstall the Bulbs using the new dual filament Bulb on the bottom

Under Dash

- Unhook the pink wire from the Headlight Switch Terminal #S58
- Extend it by 2foot.
- Remove Orange wire from Brake light switch
Switch is mounted on the Master Brake Cylinder
insulate this wire it is no longer used
- Hook up the extended wire to the free terminal on the brake switch